
Adafruit LSM9DS1 Library Documentation

Release 1.0

Tony DiCola

Aug 21, 2018

Contents

1	Dependencies	3
2	Usage Example	5
3	Contributing	7
4	Building locally	9
4.1	Sphinx documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	adafruit_lsm9ds1	12
5.2.1	Implementation Notes	12
6	Indices and tables	15
	Python Module Index	17

CircuitPython module for the LSM9DS1 accelerometer, magnetometer, gyroscope.

CHAPTER 1

Dependencies

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Usage Example

See examples/lsm9ds1_simpletest.py for a demo of the usage.

CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Building locally

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-lsm9ds1 --
˓→library_location .
```

4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

CHAPTER 5

Table of Contents

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/lsm9ds1_simpletest.py

```
1 # Simple demo of the LSM9DS1 accelerometer, magnetometer, gyroscope.
2 # Will print the acceleration, magnetometer, and gyroscope values every second.
3 import time
4
5 import board
6 import busio
7 # import digitalio # Use when connected over SPI
8
9 import adafruit_lsm9ds1
10
11
12 # You have a couple options for wiring this sensor, either I2C (recommended)
13 # or a SPI connection. Choose _one_ option below and uncomment it:
14
15 # I2C connection:
16 i2c = busio.I2C(board.SCL, board.SDA)
17 sensor = adafruit_lsm9ds1.LSM9DS1_I2C(i2c)
18
19 # SPI connection:
20 #spi = busio.SPI(board.SCK, MOSI=board.MOSI, MISO=board.MISO)
21 #xgcs = digitalio.DigitalInOut(board.D5)  # Pin connected to XGCS (accel/gyro chip_
22 #select).
23 #mcs = digitalio.DigitalInOut(board.D6)  # Pin connected to MCS (magnetometer chip_
24 #select).
25 #sensor = adafruit_lsm9ds1.LSM9DS1_SPI(spi, xgcs, mcs)
26
27 # Main loop will read the acceleration, magnetometer, gyroscope, Temperature
```

(continues on next page)

(continued from previous page)

```
26 # values every second and print them out.
27 while True:
28     # Read acceleration, magnetometer, gyroscope, temperature.
29     accel_x, accel_y, accel_z = sensor.accelerometer
30     mag_x, mag_y, mag_z = sensor.magnetometer
31     gyro_x, gyro_y, gyro_z = sensor.gyroscope
32     temp = sensor.temperature
33     # Print values.
34     print('Acceleration (m/s^2): ({0:0.3f}, {1:0.3f}, {2:0.3f})'.format(accel_x, accel_
35     ↪y, accel_z))
36     print('Magnetometer (gauss): ({0:0.3f}, {1:0.3f}, {2:0.3f})'.format(mag_x, mag_y, mag_z))
37     print('Gyroscope (degrees/sec): ({0:0.3f}, {1:0.3f}, {2:0.3f})'.format(gyro_x, gyro_y, gyro_z))
38     print('Temperature: {0:0.3f}C'.format(temp))
39     # Delay for a second.
        time.sleep(1.0)
```

5.2 adafruit_lsm9ds1

CircuitPython module for the LSM9DS1 accelerometer, magnetometer, gyroscope. Based on the driver from: https://github.com/adafruit/Adafruit_LSM9DS1

See examples/simpletest.py for a demo of the usage.

- Author(s): Tony DiCola

5.2.1 Implementation Notes

Hardware:

- Adafruit 9-DOF Accel/Mag/Gyro+Temp Breakout Board - LSM9DS1 (Product ID: 3387)

Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

```
class adafruit_lsm9ds1.LSM9DS1
    Driver for the LSM9DS1 accelerometer, magnetometer, gyroscope.

    accel_range
        The accelerometer range. Must be a value of: - ACCEL RANGE_2G - ACCEL RANGE_4G - ACCEL RANGE_8G - ACCEL RANGE_16G

    accelerometer
        The accelerometer X, Y, Z axis values as a 3-tuple of m/s^2 values.

    gyro_scale
        The gyroscope scale. Must be a value of: - GYROSCALE_245DPS - GYROSCALE_500DPS - GYROSCALE_2000DPS

    gyroscope
        The gyroscope X, Y, Z axis values as a 3-tuple of degrees/second values.
```

mag_gain

The magnetometer gain. Must be a value of: - MAGGAIN_4GAUSS - MAGGAIN_8GAUSS - MAGGAIN_12GAUSS - MAGGAIN_16GAUSS

magnetometer

The magnetometer X, Y, Z axis values as a 3-tuple of gauss values.

read_accel_raw()

Read the raw accelerometer sensor values and return it as a 3-tuple of X, Y, Z axis values that are 16-bit unsigned values. If you want the acceleration in nice units you probably want to use the accelerometer property!

read_gyro_raw()

Read the raw gyroscope sensor values and return it as a 3-tuple of X, Y, Z axis values that are 16-bit unsigned values. If you want the gyroscope in nice units you probably want to use the gyroscope property!

read_mag_raw()

Read the raw magnetometer sensor values and return it as a 3-tuple of X, Y, Z axis values that are 16-bit unsigned values. If you want the magnetometer in nice units you probably want to use the magnetometer property!

read_temp_raw()

Read the raw temperature sensor value and return it as a 12-bit signed value. If you want the temperature in nice units you probably want to use the temperature property!

temperature

The temperature of the sensor in degrees Celsius.

class adafruit_lsm9ds1.LSM9DS1_I2C(i2c)

Driver for the LSM9DS1 connect over I2C.

class adafruit_lsm9ds1.LSM9DS1_SPI(spi, xgcs, mcs)

Driver for the LSM9DS1 connect over SPI.

CHAPTER 6

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

adafruit_lsm9ds1, 12

Index

A

accel_range (adafruit_lsm9ds1.LSM9DS1 attribute), [12](#)
accelerometer (adafruit_lsm9ds1.LSM9DS1 attribute), [12](#)
adafruit_lsm9ds1 (module), [12](#)

G

gyro_scale (adafruit_lsm9ds1.LSM9DS1 attribute), [12](#)
gyroscope (adafruit_lsm9ds1.LSM9DS1 attribute), [12](#)

L

LSM9DS1 (class in adafruit_lsm9ds1), [12](#)
LSM9DS1_I2C (class in adafruit_lsm9ds1), [13](#)
LSM9DS1_SPI (class in adafruit_lsm9ds1), [13](#)

M

mag_gain (adafruit_lsm9ds1.LSM9DS1 attribute), [12](#)
magnetometer (adafruit_lsm9ds1.LSM9DS1 attribute),
 [13](#)

R

read_accel_raw() (adafruit_lsm9ds1.LSM9DS1 method),
 [13](#)
read_gyro_raw() (adafruit_lsm9ds1.LSM9DS1 method),
 [13](#)
read_mag_raw() (adafruit_lsm9ds1.LSM9DS1 method),
 [13](#)
read_temp_raw() (adafruit_lsm9ds1.LSM9DS1 method),
 [13](#)

T

temperature (adafruit_lsm9ds1.LSM9DS1 attribute), [13](#)