
Airlab Documentation

Release 0.1

Robin Sandkuehler Christoph Jud

Aug 20, 2019

Building Blocks:

1	registration	3
2	transformation	5
3	loss	9
4	regulariser	13
5	utils	17
6	Indices and tables	21
	Python Module Index	23
	Index	25

AirLab is an open laboratory for medical image registration. It provides an environment for rapid prototyping and reproduction of registration algorithms. The unique feature of AirLab is, that the analytic gradients of the objective function are computed automatically with fosters rapid prototyping. In addition, the device on which the computations are performed, on a CPU or a GPU, is transparent. AirLab is implemented in Python using PyTorch as tensor and optimization library and SimpleITK for basic image IO. It profits therefore from recent advances made by the machine learning community.

Authors: Robin Sandkuehler and Christoph Jud


```
class airlab.registration.PairwiseRegistration (verbose=True)
```

```
    start (EarlyStopping=False, StopPatience=10)
```

```
class airlab.registration.DemonsRegistraion (verbose=True)
```

```
    set_regulariser (regulariser)
```

```
    start ()
```


2.1 Pairwise Transformation

```
class airlab.transformation.pairwise.AffineTransformation (moving_image,
                                                         opt_cm=False)
```

Affine centred transformation for 2D and 3D.

Parameters

- **moving_image** (*Image*) – moving image for the registration
- **opt_cm** (*bool*) – using center of as parameter for the optimisation

forward ()

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
set_parameters (t, phi, scale, shear, rotation_center=None)
```

Set parameters manually

t (array): 2 or 3 dimensional array specifying the spatial translation
phi (array): 1 or 3 dimensional array specifying the rotation angles
scale (array): 2 or 3 dimensional array specifying the scale in each dimension
shear (array): 2 or 6 dimensional array specifying the shear in each dimension: *yx, xy, zx, zy, xz, yz*
rotation_center (array): 2 or 3 dimensional array specifying the rotation center (default is zeros)

```
class airlab.transformation.pairwise.BsplineTransformation (image_size,
                                                         sigma, diffeomorphic=False,
                                                         order=2,
                                                         dtype=torch.float32,
                                                         device='cpu')
```

```
class airlab.transformation.pairwise.NonParametricTransformation (image_size,
                                                                diffeomor-
                                                                phic=False,
                                                                dtype=torch.float32,
                                                                de-
                                                                vice='cpu')
```

None parametric transformation

forward ()

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

set_start_parameter (*parameters*)

```
class airlab.transformation.pairwise.RigidTransformation (moving_image,
                                                                opt_cm=False)
```

Rigid centred transformation for 2D and 3D.

Parameters

- **moving_image** (`Image`) – moving image for the registration
- **opt_cm** (`bool`) – using center of as parameter for the optimisation

compute_displacement (*transformation_matrix*)

forward ()

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

init_translation (*fixed_image*)

Initialize the translation parameters with the difference between the center of mass of the fixed and the moving image

Parameters **fixed_image** (`Image`) – Fixed image for the registration

print ()

set_parameters (*t, phi, rotation_center=None*)

Set parameters manually

t (array): 2 or 3 dimensional array specifying the spatial translation *phi* (array): 1 or 3 dimensional array specifying the rotation angles *rotation_center* (array): 2 or 3 dimensional array specifying the rotation center (default is zeros)

transformation_matrix

```
class airlab.transformation.pairwise.SimilarityTransformation (moving_image,
                                                                opt_cm=False)
```

Similarity centred transformation for 2D and 3D. :param moving_image: moving image for the registration

:type moving_image: Image :param opt_cm: using center of as parameter for the optimisation :type opt_cm: bool

forward()

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

set_parameters (*t, phi, scale, rotation_center=None*)

Set parameters manually

t (array): 2 or 3 dimensional array specifying the spatial translation
phi (array): 1 or 3 dimensional array specifying the rotation angles
scale (array): 2 or 3 dimensional array specifying the scale in each dimension
rotation_center (array): 2 or 3 dimensional array specifying the rotation center (default is zeros)

```
class airlab.transformation.pairwise.WendlandKernelTransformation (image_size,
                                                                    sigma,
                                                                    cp_scale=2,
                                                                    diffeomor-
                                                                    phic=False,
                                                                    ktype='C4',
                                                                    dtype=torch.float32,
                                                                    de-
                                                                    vice='cpu')
```

Wendland Kernel Transform:

Implements the kernel transform with the Wendland basis

Parameters

- **sigma** – specifies how many control points are used (each sigma pixels)
- **cp_scale** – specifies the extent of the kernel. how many control points are in the support of the kernel

2.2 Transformation Utils

```
class airlab.transformation.utils.Diffeomorphic (image_size=None,          scaling=10,
                                                                    dtype=torch.float32, device='cpu')
```

Diffeomorphic transformation. This class computes the matrix exponential of a given flow field using the scaling and squaring algorithm according to:

Unsupervised Learning for Fast Probabilistic Diffeomorphic Registration Adrian V. Dalca, Guha Balakrishnan, John Guttag, Mert R. Sabuncu MICCAI 2018 and Diffeomorphic Demons: Efficient Non-parametric Image Registration Tom Vercauteren et al., 2008

calculate (*displacement*)

static diffeomorphic_2D (*displacement, grid, scaling=-1*)

static diffeomorphic_3D (*displacement, grid, scaling=-1*)

set_image_size (*image_size*)

```
airlab.transformation.utils.compute_grid (image_size, dtype=torch.float32, device='cpu')
```

```
airlab.transformation.utils.displacement_to_unit_displacement (displacement)  
airlab.transformation.utils.rotation_matrix (phi_x, phi_y, phi_z, dtype=torch.float32, de-  
       vice='cpu', homogeneous=False)  
airlab.transformation.utils.unit_displacement_to_displacement (displacement)  
airlab.transformation.utils.upsample_displacement (displacement, new_size, interpola-  
       tion='linear')  
    Upsample displacement field  
airlab.transformation.utils.warp_image (image, displacement)
```

3.1 Pairwise Loss

```
class airlab.loss.pairwise.LCC (fixed_image, moving_image, fixed_mask=None,
                               moving_mask=None, sigma=3, kernel_type='box',
                               size_average=True, reduce=True)
```

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.loss.pairwise.MI (fixed_image, moving_image, fixed_mask=None, moving_mask=None,
                              bins=64, sigma=3, spatial_samples=0.1,
                              background=None, size_average=True, reduce=True)
```

Implementation of the Mutual Information image loss.

$$S_{MI} := H(F, M) - H(F|M) - H(M|F)$$

Parameters

- **fixed_image** (`Image`) – Fixed image for the registration
- **moving_image** (`Image`) – Moving image for the registration
- **bins** (`int`) – Number of bins for the intensity distribution
- **sigma** (`float`) – Kernel sigma for the intensity distribution approximation

- **spatial_samples** (*float*) – Percentage of pixels used for the intensity distribution approximation
- **background** – Method to handle background pixels. *None*: Set background to the min value of image “mean”: Set the background to the mean value of the image float: Set the background value to the input value
- **size_average** (*bool*) – Average loss function
- **reduce** (*bool*) – Reduce loss function to a single value

bins

bins_fixed_image

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

sigma

class `airlab.loss.pairwise.MSE` (*fixed_image*, *moving_image*, *fixed_mask=None*, *moving_mask=None*, *size_average=True*, *reduce=True*)

The mean square error loss is a simple and fast to compute point-wise measure which is well suited for monomodal image registration.

$$S_{\text{MSE}} := \frac{1}{|\mathcal{X}|} \sum_{x \in \mathcal{X}} \left(I_M(x + f(x)) - I_F(x) \right)^2$$

Parameters

- **fixed_image** (*Image*) – Fixed image for the registration
- **moving_image** (*Image*) – Moving image for the registration
- **size_average** (*bool*) – Average loss function
- **reduce** (*bool*) – Reduce loss function to a single value

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

class `airlab.loss.pairwise.NCC` (*fixed_image*, *moving_image*, *fixed_mask=None*, *moving_mask=None*)

The normalized cross correlation loss is a measure for image pairs with a linear intensity relation.

$$S_{\text{NCC}} := \frac{\sum I_F \cdot (I_M \circ f) - \sum E(I_F)E(I_M \circ f)}{|\mathcal{X}| \cdot \sum \text{Var}(I_F)\text{Var}(I_M \circ f)}$$

Parameters

- **fixed_image** (*Image*) – Fixed image for the registration
- **moving_image** (*Image*) – Moving image for the registration

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.loss.pairwise.NGF(fixed_image, moving_image, fixed_mask=None, moving_mask=None, epsilon=1e-05, size_average=True, reduce=True)
```

Implementation of the Normalized Gradient Fields image loss.

Parameters

- **fixed_image** (*Image*) – Fixed image for the registration
- **moving_image** (*Image*) – Moving image for the registration
- **fixed_mask** (*Tensor*) – Mask for the fixed image
- **moving_mask** (*Tensor*) – Mask for the moving image
- **epsilon** (*float*) – Regulariser for the gradient amplitude
- **size_average** (*bool*) – Average loss function
- **reduce** (*bool*) – Reduce loss function to a single value

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.loss.pairwise.SSIM(fixed_image, moving_image, fixed_mask=None, moving_mask=None, sigma=[3], dim=2, kernel_type='box', alpha=1, beta=1, gamma=1, c1=1e-05, c2=1e-05, c3=1e-05, size_average=True, reduce=True)
```

Implementation of the Structural Similarity Image Measure loss.

Parameters

- **fixed_image** (*Image*) – Fixed image for the registration
- **moving_image** (*Image*) – Moving image for the registration
- **fixed_mask** (*Tensor*) – Mask for the fixed image
- **moving_mask** (*Tensor*) – Mask for the moving image
- **sigma** (*float*) – Sigma for the kernel

- **kernel_type** (*string*) – Type of kernel i.e. gaussian, box
- **alpha** (*float*) – Controls the influence of the luminance value
- **beta** (*float*) – Controls the influence of the contrast value
- **gamma** (*float*) – Controls the influence of the structure value
- **c1** (*float*) – Numerical constant for the luminance value
- **c2** (*float*) – Numerical constant for the contrast value
- **c3** (*float*) – Numerical constant for the structure value
- **size_average** (*bool*) – Average loss function
- **reduce** (*bool*) – Reduce loss function to a single value

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

4.1 Demons Regulariser

```
class airlab.regulariser.demons.GaussianRegulariser (pixel_spacing, sigma,  
                                                    dtype=torch.float32, de-  
                                                    vice='cpu')  
  
    regularise (data)
```

4.1.1 Graph Diffusion Regulariser

```
class airlab.regulariser.demons.GraphDiffusionRegulariser (image_size,  
                                                            pixel_spacing,  
                                                            edge_updater, phi=1,  
                                                            dtype=torch.float32,  
                                                            device='cpu')  
  
    get_edge_image ()  
    regularise (data)  
    set_krylov_dim (krylov_dim)  
  
class airlab.regulariser.demons.EdgeUpdaterDisplacementIntensities (pixel_spacing,  
                                                                      image,  
                                                                      edge_window=0.9,  
                                                                      edge_mean=False)  
  
    update (data)  
  
class airlab.regulariser.demons.EdgeUpdaterIntensities (pixel_spacing, image,  
                                                         scale=1, edge_window=0.9,  
                                                         edge_mean=False)
```

`set_scale` (*scale*)

`update` (*data*)

4.2 Displacement Regulariser

```
class airlab.regulariser.displacement.DiffusionRegulariser (pixel_spacing,  
size_average=True,  
reduce=True)
```

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.regulariser.displacement.IsotropicTVRegulariser (pixel_spacing,  
size_average=True,  
reduce=True)
```

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.regulariser.displacement.SparsityRegulariser (size_average=True, re-  
duce=True)
```

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.regulariser.displacement.TVRegulariser (pixel_spacing,  
size_average=True, re-  
duce=True)
```

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

4.3 Parameter Regulariser

```
class airlab.regulariser.parameter.DiffusionRegulariser (pixel_spacing,  
                                                    size_average=True,  
                                                    reduce=True)
```

forward (*displacement*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.regulariser.parameter.IsotropicTVRegulariser (parameter_name,  
                                                         scaling=[1],  
                                                         size_average=True,  
                                                         reduce=True)
```

forward (*parameters*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.regulariser.parameter.SparsityRegulariser (parameter_name,  
                                                         size_average=True,      re-  
                                                         duce=True)
```

forward (*parameters*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

```
class airlab.regulariser.parameter.TVRegulariser (parameter_name,      scaling=[1],  
                                                  size_average=True, reduce=True)
```

forward (*parameters*)

Defines the computation performed at every call.

Should be overridden by all subclasses.

Note: Although the recipe for forward pass needs to be defined within this function, one should call the `Module` instance afterwards instead of this since the former takes care of running the registered hooks while the latter silently ignores them.

5.1 Image

```
class airlab.utils.image.Displacement (*args, **kwargs)
```

```
    itk ()
```

Returns a SimpleITK image

Note: the order of axis is flipped back to the convention of SimpleITK

```
    magnitude ()
```

```
    numpy ()
```

Returns a numpy array

```
    static read (filename, dtype=torch.float32, device='cpu')
```

Static method to directly read a displacement field through the Image class

filename (str): filename of the displacement field dtype: specific dtype for representing the tensor device: on which device the displacement field has to be allocated return (Displacement): an airlab displacement field

```
class airlab.utils.image.Image (*args, **kwargs)
```

Class representing an image in airlab

```
    initializeForImages (sitk_image, dtype=None, device='cpu')
```

Constructor for SimpleITK image

Note: the order of axis are flipped in order to follow the convention of numpy and torch

sitk_image (sitk.SimpleITK.Image): SimpleITK image dtype: pixel type ('cpu'/'cuda'): on which device the image should be allocated return (Image): an airlab image object

```
    initializeForTensors (tensor_image, image_size, image_spacing, image_origin)
```

Constructor for torch tensors and numpy ndarrays

Args: `tensor_image` (np.ndarray | th.Tensor): n-dimensional tensor, where the last dimensions are the image dimensions while the preceding dimensions need to empty `image_size` (array | list | tuple): number of pixels in each space dimension `image_spacing` (array | list | tuple): pixel size for each space dimension `image_origin` (array | list | tuple): physical coordinate of the first pixel :return (Image): an airlab image object

itk ()

Returns a SimpleITK image

Note: the order of axis is flipped back to the convention of SimpleITK

numpy ()

Returns a numpy array

static read (*filename*, *dtype=torch.float32*, *device='cpu'*)

Static method to directly read an image through the Image class

filename (str): filename of the image *dtype*: specific dtype for representing the tensor *device*: on which device the image has to be allocated return (Image): an airlab image

to (*dtype=None*, *device='cpu'*)

Converts the image tensor to a specified dtype and moves it to the specified device

write (*filename*)

Write an image to hard drive

Note: order of axis are flipped to have the representation of SimpleITK again

filename (str): filename where the image is written

`airlab.utils.image.create_displacement_image_from_image` (*tensor_displacement*, *image*)

`airlab.utils.image.create_image_from_image` (*tensor_image*, *image*)

`airlab.utils.image.create_image_pyramid` (*image*, *down_sample_factor*)

`airlab.utils.image.create_tensor_image_from_itk_image` (*itk_image*,
dtype=torch.float32, *device='cpu'*)

`airlab.utils.image.flip` (*x*, *dim*)

Flip order of a specific dimension *dim*

x (Tensor): input tensor *dim* (int): axis which should be flipped return (Tensor): returns the tensor with the specified axis flipped

`airlab.utils.image.image_from_numpy` (*image*, *pixel_spacing*, *image_origin*,
dtype=torch.float32, *device='cpu'*)

`airlab.utils.image.read_image_as_tensor` (*filename*, *dtype=torch.float32*, *device='cpu'*)

5.2 Kernel Function

`airlab.utils.kernelFunction.bspline_kernel` (*sigma*, *order=2*, *dim=1*, *asTensor=False*,
dtype=torch.float32, *device='cpu'*)

`airlab.utils.kernelFunction.bspline_kernel_1d` (*sigma*, *order=2*, *asTensor=False*,
dtype=torch.float32, *device='cpu'*)

`airlab.utils.kernelFunction.bspline_kernel_2d` (*sigma=[1, 1]*, *order=2*, *asTensor=False*,
dtype=torch.float32, *device='cpu'*)

```

airlab.utils.kernelFunction.bspline_kernel_3d(sigma=[1, 1, 1], order=2, asTensor=False, dtype=torch.float32, device='cpu')
airlab.utils.kernelFunction.gaussian_kernel(sigma, dim=1, asTensor=False, dtype=torch.float32, device='cpu')
airlab.utils.kernelFunction.gaussian_kernel_1d(sigma, asTensor=False, dtype=torch.float32, device='cpu')
airlab.utils.kernelFunction.gaussian_kernel_2d(sigma, asTensor=False, dtype=torch.float32, device='cpu')
airlab.utils.kernelFunction.gaussian_kernel_3d(sigma, asTensor=False, dtype=torch.float32, device='cpu')
airlab.utils.kernelFunction.wendland_kernel(sigma, dim=1, type='C4', asTensor=False, dtype=torch.float32, device='cpu')
airlab.utils.kernelFunction.wendland_kernel_1d(sigma, type='C4', asTensor=False, dtype=torch.float32, device='cpu')
airlab.utils.kernelFunction.wendland_kernel_2d(sigma, type='C4', asTensor=False, dtype=torch.float32, device='cpu')
airlab.utils.kernelFunction.wendland_kernel_3d(sigma, type='C4', asTensor=False, dtype=torch.float32, device='cpu')

```

5.3 Graph

```

class airlab.utils.graph.Graph(graph_size, dtype=torch.float32, device='cpu')

```

5.4 Matrix

```

class airlab.utils.matrix.LaplaceMatrix(number_of_nodes, diag_elements,
                                         dtype=torch.float32, device='cpu')

```

```

    full()

```

```

    update()

```

```

class airlab.utils.matrix.MatrixDiagonalElement(edge_index, edge_values, offset,
                                                  dtype=torch.float32, device='cpu')

```

```

airlab.utils.matrix.band_mv(A, x)

```

```

airlab.utils.matrix.expm_eig(A)

```

```

airlab.utils.matrix.expm_krylov(A, x, phi=1, krylov_dim=30, inplace=True)

```


CHAPTER 6

Indices and tables

- genindex
- modindex

a

`airlab.loss.pairwise`, 9
`airlab.registration`, 3
`airlab.regulariser.displacement`, 14
`airlab.regulariser.parameter`, 15
`airlab.transformation.pairwise`, 5
`airlab.transformation.utils`, 7
`airlab.utils.graph`, 19
`airlab.utils.image`, 17
`airlab.utils.kernelFunction`, 18
`airlab.utils.matrix`, 19

A

AffineTransformation (class in *airlab.transformation.pairwise*), 5
 airlab.loss.pairwise (module), 9
 airlab.registration (module), 3
 airlab.regulariser.displacement (module), 14
 airlab.regulariser.parameter (module), 15
 airlab.transformation.pairwise (module), 5
 airlab.transformation.utils (module), 7
 airlab.utils.graph (module), 19
 airlab.utils.image (module), 17
 airlab.utils.kernelFunction (module), 18
 airlab.utils.matrix (module), 19

B

band_mv() (in module *airlab.utils.matrix*), 19
 bins (*airlab.loss.pairwise.MI* attribute), 10
 bins_fixed_image (*airlab.loss.pairwise.MI* attribute), 10
 bspline_kernel() (in module *airlab.utils.kernelFunction*), 18
 bspline_kernel_1d() (in module *airlab.utils.kernelFunction*), 18
 bspline_kernel_2d() (in module *airlab.utils.kernelFunction*), 18
 bspline_kernel_3d() (in module *airlab.utils.kernelFunction*), 18
 BsplineTransformation (class in *airlab.transformation.pairwise*), 5

C

calculate() (*airlab.transformation.utils.Diffeomorphic* method), 7
 compute_displacement() (*airlab.transformation.pairwise.RigidTransformation* method), 6
 compute_grid() (in module *airlab.transformation.utils*), 7

create_displacement_image_from_image() (in module *airlab.utils.image*), 18
 create_image_from_image() (in module *airlab.utils.image*), 18
 create_image_pyramid() (in module *airlab.utils.image*), 18
 create_tensor_image_from_itk_image() (in module *airlab.utils.image*), 18

D

DemonsRegistraion (class in *airlab.registration*), 3
 Diffeomorphic (class in *airlab.transformation.utils*), 7
 diffeomorphic_2D() (*airlab.transformation.utils.Diffeomorphic* static method), 7
 diffeomorphic_3D() (*airlab.transformation.utils.Diffeomorphic* static method), 7
 DiffusionRegulariser (class in *airlab.regulariser.displacement*), 14
 DiffusionRegulariser (class in *airlab.regulariser.parameter*), 15
 Displacement (class in *airlab.utils.image*), 17
 displacement_to_unit_displacement() (in module *airlab.transformation.utils*), 8

E

EdgeUpdaterDisplacementIntensities (class in *airlab.regulariser.demons*), 13
 EdgeUpdaterIntensities (class in *airlab.regulariser.demons*), 13
 expm_eig() (in module *airlab.utils.matrix*), 19
 expm_krylov() (in module *airlab.utils.matrix*), 19

F

flip() (in module *airlab.utils.image*), 18
 forward() (*airlab.loss.pairwise.LCC* method), 9
 forward() (*airlab.loss.pairwise.MI* method), 10

forward() (*airlab.loss.pairwise.MSE method*), 10
 forward() (*airlab.loss.pairwise.NCC method*), 11
 forward() (*airlab.loss.pairwise.NGF method*), 11
 forward() (*airlab.loss.pairwise.SSIM method*), 12
 forward() (*airlab.regulariser.displacement.DiffusionRegulariser method*), 14
 forward() (*airlab.regulariser.displacement.IsotropicTVRegulariser method*), 14
 forward() (*airlab.regulariser.displacement.SparsityRegulariser method*), 14
 forward() (*airlab.regulariser.displacement.TVRegulariser method*), 14
 forward() (*airlab.regulariser.parameter.DiffusionRegulariser method*), 15
 forward() (*airlab.regulariser.parameter.IsotropicTVRegulariser method*), 15
 forward() (*airlab.regulariser.parameter.SparsityRegulariser method*), 15
 forward() (*airlab.regulariser.parameter.TVRegulariser method*), 15
 forward() (*airlab.transformation.pairwise.AffineTransformation method*), 5
 forward() (*airlab.transformation.pairwise.NonParametricTransformation method*), 6
 forward() (*airlab.transformation.pairwise.RigidTransformation method*), 6
 forward() (*airlab.transformation.pairwise.SimilarityTransformation method*), 7
 full() (*airlab.utils.matrix.LaplaceMatrix method*), 19

G

gaussian_kernel() (in module *airlab.utils.kernelFunction*), 19
 gaussian_kernel_1d() (in module *airlab.utils.kernelFunction*), 19
 gaussian_kernel_2d() (in module *airlab.utils.kernelFunction*), 19
 gaussian_kernel_3d() (in module *airlab.utils.kernelFunction*), 19
 GaussianRegulariser (class in *airlab.regulariser.demons*), 13
 get_edge_image() (*airlab.regulariser.demons.GraphDiffusionRegulariser method*), 13
 Graph (class in *airlab.utils.graph*), 19
 GraphDiffusionRegulariser (class in *airlab.regulariser.demons*), 13

I

Image (class in *airlab.utils.image*), 17
 image_from_numpy() (in module *airlab.utils.image*), 18
 init_translation() (*airlab.transformation.pairwise.RigidTransformation method*), 6
 initializeForImages() (*airlab.utils.image.Image method*), 17
 initializeForTensors() (*airlab.utils.image.Image method*), 17
 IsotropicTVRegulariser (class in *airlab.regulariser.parameter*), 15
 IsotropicTVRegulariser (class in *airlab.regulariser.parameter*), 15
 itk() (*airlab.utils.image.Displacement method*), 17
 itk() (*airlab.utils.image.Image method*), 18

L

LaplaceMatrix (class in *airlab.utils.matrix*), 19
 LPS (class in *airlab.loss.pairwise*), 9

M

magnitude() (*airlab.utils.image.Displacement method*), 17
 MatrixDiagonalElement (class in *airlab.utils.matrix*), 19
 MI (class in *airlab.loss.pairwise*), 9
 MSE (class in *airlab.loss.pairwise*), 10

N

NCC (class in *airlab.loss.pairwise*), 10
 NGF (class in *airlab.loss.pairwise*), 11
 NonParametricTransformation (class in *airlab.transformation.pairwise*), 5
 numpy() (*airlab.utils.image.Displacement method*), 17
 numpy() (*airlab.utils.image.Image method*), 18

P

PairwiseRegistration (class in *airlab.registration*), 3
 print() (*airlab.transformation.pairwise.RigidTransformation method*), 6

R

read() (*airlab.utils.image.Displacement static method*), 17
 read() (*airlab.utils.image.Image static method*), 18
 read_image_as_tensor() (in module *airlab.utils.image*), 18
 regularise() (*airlab.regulariser.demons.GaussianRegulariser method*), 13
 regularise() (*airlab.regulariser.demons.GraphDiffusionRegulariser method*), 13
 RigidTransformation (class in *airlab.transformation.pairwise*), 6
 rotation_matrix() (in module *airlab.transformation.utils*), 8

S

set_image_size() (airlab.transformation.utils.Diffeomorphic method), 7
 set_krylov_dim() (airlab.regulariser.demons.GraphDiffusionRegulariser method), 13
 set_parameters() (airlab.transformation.pairwise.AffineTransformation method), 5
 set_parameters() (airlab.transformation.pairwise.RigidTransformation method), 6
 set_parameters() (airlab.transformation.pairwise.SimilarityTransformation method), 7
 set_regularizer() (airlab.registration.DemonsRegistration method), 3
 set_scale() (airlab.regulariser.demons.EdgeUpdaterIntensities method), 13
 set_start_parameter() (airlab.transformation.pairwise.NonParametricTransformation method), 6
 sigma (airlab.loss.pairwise.MI attribute), 10
 SimilarityTransformation (class in airlab.transformation.pairwise), 6
 SparsityRegulariser (class in airlab.regulariser.displacement), 14
 SparsityRegulariser (class in airlab.regulariser.parameter), 15
 SSIM (class in airlab.loss.pairwise), 11
 start() (airlab.registration.DemonsRegistration method), 3
 start() (airlab.registration.PairwiseRegistration method), 3

T

to() (airlab.utils.image.Image method), 18
 transformation_matrix (airlab.transformation.pairwise.RigidTransformation attribute), 6
 TVRegulariser (class in airlab.regulariser.displacement), 14
 TVRegulariser (class in airlab.regulariser.parameter), 15

U

unit_displacement_to_displacement() (in module airlab.transformation.utils), 8
 update() (airlab.regulariser.demons.EdgeUpdaterDisplacementIntensities method), 13
 update() (airlab.regulariser.demons.EdgeUpdaterIntensities method), 14

update() (airlab.utils.matrix.LaplaceMatrix method), 19

upsample_displacement() (in module airlab.transformation.utils), 8

W

warp_image() (in module airlab.transformation.utils), 8

wendland_kernel() (in module airlab.utils.kernelFunction), 19

wendland_kernel_1d() (in module airlab.utils.kernelFunction), 19

wendland_kernel_2d() (in module airlab.utils.kernelFunction), 19

wendland_kernel_3d() (in module airlab.utils.kernelFunction), 19

WendlandKernelTransformation (class in airlab.transformation.pairwise), 7

write() (airlab.utils.image.Image method), 18