

---

# AdafruitCrickit Library Documentation

*Release 1.0*

**Dan Halbert**

**Jan 14, 2020**



---

## Contents

---

<b>1</b>	<b>Dependencies</b>	<b>3</b>
<b>2</b>	<b>Installing from PyPI</b>	<b>5</b>
<b>3</b>	<b>Usage Example</b>	<b>7</b>
<b>4</b>	<b>Contributing</b>	<b>9</b>
<b>5</b>	<b>Documentation</b>	<b>11</b>
<b>6</b>	<b>Table of Contents</b>	<b>13</b>
6.1	Examples .....	13
6.2	adafruit_crickit .....	13
6.2.1	Implementation Notes .....	13
<b>7</b>	<b>Indices and tables</b>	<b>17</b>
	<b>Python Module Index</b>	<b>19</b>
	<b>Index</b>	<b>21</b>



This convenience library makes coding for the Crickit robotics boards simpler and shorter.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- [Adafruit seesaw library](#)
- [Adafruit Motor library](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).



## CHAPTER 2

---

### Installing from PyPI

---

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-crickit
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-crickit
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name  
python3 -m venv .env  
source .env/bin/activate  
pip3 install adafruit-circuitpython-crickit
```



## CHAPTER 3

---

### Usage Example

---

This examples shows how to control all the devices supported by the library. In most cases you just need a couple of imports.

```
# This is a mock example showing typical usage of the library for each kind of device.

from adafruit_crickit import crickit

# Add this import if using stepper motors.
# It will expose constants saying how to step: stepper.FORWARD, stepper.BACKWARD, etc.
from adafruit_motor import stepper

# Set servo 1 to 90 degrees
crickit.servo_1.angle = 90

# Change servo settings.
crickit.servo_1.actuation_range = 135
crickit.servo_1.set_pulse_width_range(min_pulse=850, max_pulse=2100)

# You can assign a device to a variable to get a shorter name.
servo_2 = crickit.servo_2
servo_2.throttle = 0

# Run a continous servo on Servo 2 backwards at half speed.
crickit.continuous_servo_2.throttle = -0.5

# Run the motor on Motor 1 terminals at half speed.
crickit.dc_motor_1.throttle = 0.5

# Set Drive 1 terminal to 3/4 strength.
crickit.drive_1.fraction = 0.75

if crickit.touch_1.value:
    print("Touched terminal Touch 1")
```

(continues on next page)

(continued from previous page)

```
# A single stepper motor uses up all the motor terminals.
crickit.stepper_motor.onestep(direction=stepper.FORWARD)

# You can also use the Drive terminals for a stepper motor
crickit.drive_stepper_motor.onestep(direction=stepper.BACKWARD)

# Note: On CPX Crickit, NeoPixel pin is normally connected to A1, not to seesaw,
# so this part of the demo cannot control the NeoPixel terminal.
# Strip or ring of 8 NeoPixels
crickit.init_neopixel(8)
crickit.neopixel.fill((100, 100, 100))

# Set the Crickit's on-board NeoPixel to a dim purple.
crickit.onboard_pixel.brightness = 0.01
crickit.onboard_pixel[0] = (255, 24, 255)
# or
crickit.onboard_pixel.fill((255, 24, 255))
```

## CHAPTER 4

---

### Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



## CHAPTER 5

---

### Documentation

---

For information on building library documentation, please check out [this guide](#).



### 6.1 Examples

The `examples` directory contains simple examples for controlling a number of different devices, such as servos and DC motors.

### 6.2 `adafruit_crickit`

Convenience library for using the Adafruit Crickit robotics boards.

- Author(s): Dan Halbert

#### 6.2.1 Implementation Notes

**Hardware:**

Adafruit Crickit for Circuit Playground Express Adafruit Crickit FeatherWing

**Software and Dependencies:**

- Adafruit CircuitPython firmware for the supported boards: <https://github.com/adafruit/circuitpython/releases>

**class** `adafruit_crickit.Crickit` (*seesaw*)

Represents a Crickit board. Provides a number of devices available via properties, such as `servo_1`. Devices are created on demand the first time they are referenced.

It's fine to refer a device multiple times via its property, but it's faster and results in more compact code to assign a device to a variable.

```
import time
from adafruit_crickit import crickit
```

(continues on next page)

(continued from previous page)

```
# This is fine:
crickit.servo_1.angle = 0
time.sleep(1)
crickit.servo_1.angle = 90
time.sleep(1)

# This is slightly faster and more compact:
servo_1 = crickit.servo_1
servo_1.angle = 0
time.sleep(1)
servo_1.angle = 90
time.sleep(1)
```

**SIGNAL1 = 2**

Signal 1 terminal

**SIGNAL2 = 3**

Signal 2 terminal

**SIGNAL3 = 40**

Signal 3 terminal

**SIGNAL4 = 41**

Signal 4 terminal

**SIGNAL5 = 11**

Signal 5 terminal

**SIGNAL6 = 10**

Signal 6 terminal

**SIGNAL7 = 9**

Signal 7 terminal

**SIGNAL8 = 8**

Signal 8 terminal

**continuous\_servo\_1**

adafruit\_motor.servo.ContinuousServo object on Servo 1 terminal

**continuous\_servo\_2**

adafruit\_motor.servo.ContinuousServo object on Servo 2 terminal

**continuous\_servo\_3**

adafruit\_motor.servo.ContinuousServo object on Servo 3 terminal

**continuous\_servo\_4**

adafruit\_motor.servo.ContinuousServo object on Servo 4 terminal

**dc\_motor\_1**

adafruit\_motor.motor.DCMotor object on Motor 1 terminals

**dc\_motor\_2**

adafruit\_motor.motor.DCMotor object on Motor 2 terminals

**drive\_1**

adafruit\_seesaw.pwmout.PWMOut object on Drive 1 terminal, with frequency=1000

**drive\_2**

adafruit\_seesaw.pwmout.PWMOut object on Drive 2 terminal, with frequency=1000

**drive\_3**

adafruit\_seesaw.pwmout.PWMOut object on Drive 3 terminal, with frequency=1000

**drive\_4**

adafruit\_seesaw.pwmout.PWMOut object on Drive 4 terminal, with frequency=1000

**drive\_stepper\_motor**

adafruit\_motor.motor.StepperMotor object on Drive terminals

**feather\_drive\_1**

adafruit\_seesaw.pwmout.PWMOut object on Crickit Featherwing Drive 1 terminal, with frequency=1000

**feather\_drive\_2**

adafruit\_seesaw.pwmout.PWMOut object on Crickit Featherwing Drive 2 terminal, with frequency=1000

**feather\_drive\_3**

adafruit\_seesaw.pwmout.PWMOut object on Crickit Featherwing Drive 3 terminal, with frequency=1000

**feather\_drive\_4**

adafruit\_seesaw.pwmout.PWMOut object on Crickit Featherwing Drive 4 terminal, with frequency=1000

**feather\_drive\_stepper\_motor**

adafruit\_motor.motor.StepperMotor object on Drive terminals on Crickit FeatherWing

**init\_neopixel** (*n*, \*, *bpp*=3, *brightness*=1.0, *auto\_write*=True, *pixel\_order*=None)

Set up a seesaw.NeoPixel object

---

**Note:** On the CPX Crickit board, the NeoPixel terminal is by default controlled by CPX pin A1, and is not controlled by seesaw. So this object will not be usable. Instead, use the regular NeoPixel library and specify board.A1 as the pin.

---

You can change the jumper connection on the bottom of the CPX Crickit board to move control of the NeoPixel terminal to seesaw pin #20 (terminal.NEOPIXEL). In addition, the Crickit FeatherWing always uses seesaw pin #20. In either of those cases, this object will work.

```
from adafruit_crickit.crickit import crickit

crickit.init_neopixel(24)
crickit.neopixel.fill((100, 0, 0))
```

**neopixel**

\adafruit\_seesaw.neopixel object on NeoPixel terminal. Raises ValueError if init\_neopixel has not been called.

**onboard\_pixel**

\adafruit\_seesaw.neopixel object on the Seesaw on-board NeoPixel. Initialize on-board NeoPixel and clear upon first use.

**reset** ()

Reset the whole Crickit board.

**seesaw**

The Seesaw object that talks to the Crickit. Use this object to manipulate the signal pins that correspond to Crickit terminals.

```
from adafruit_crickit import crickit

ss = crickit.seesaw
ss.pin_mode(crickit.SIGNAL4, ss.OUTPUT)
ss.digital_write(crickit.SIGNAL4, True)
```

**servo\_1**

adafruit\_motor.servo.Servo object on Servo 1 terminal

**servo\_2**

adafruit\_motor.servo.Servo object on Servo 2 terminal

**servo\_3**

adafruit\_motor.servo.Servo object on Servo 3 terminal

**servo\_4**

adafruit\_motor.servo.Servo object on Servo 4 terminal

**stepper\_motor**

adafruit\_motor.motor.StepperMotor object on Motor 1 and Motor 2 terminals

**touch\_1**

adafruit\_crickit.CrickitTouchIn object on Touch 1 terminal

**touch\_2**

adafruit\_crickit.CrickitTouchIn object on Touch 2 terminal

**touch\_3**

adafruit\_crickit.CrickitTouchIn object on Touch 3 terminal

**touch\_4**

adafruit\_crickit.CrickitTouchIn object on Touch 4 terminal

**class** adafruit\_crickit.**CrickitTouchIn** (*seesaw, pin*)

Imitate touchio.TouchIn.

**raw\_value**

The raw touch measurement as an *int*. (read-only)

**value**

Whether the touch pad is being touched or not. (read-only)

adafruit\_crickit.**crickit** = **None**

A singleton instance to control a single Crickit board, controlled by the default I2C pins.

# CHAPTER 7

---

## Indices and tables

---

- `genindex`
- `modindex`
- `search`



**a**

`adafruit_crickit`, 13



**A**

adafruit\_crickit (*module*), 13

**C**

continuous\_servo\_1 (*adafruit\_crickit.Crickit attribute*), 14

continuous\_servo\_2 (*adafruit\_crickit.Crickit attribute*), 14

continuous\_servo\_3 (*adafruit\_crickit.Crickit attribute*), 14

continuous\_servo\_4 (*adafruit\_crickit.Crickit attribute*), 14

Crickit (*class in adafruit\_crickit*), 13

cricket (*in module adafruit\_crickit*), 16

CrickitTouchIn (*class in adafruit\_crickit*), 16

**D**

dc\_motor\_1 (*adafruit\_crickit.Crickit attribute*), 14

dc\_motor\_2 (*adafruit\_crickit.Crickit attribute*), 14

drive\_1 (*adafruit\_crickit.Crickit attribute*), 14

drive\_2 (*adafruit\_crickit.Crickit attribute*), 14

drive\_3 (*adafruit\_crickit.Crickit attribute*), 14

drive\_4 (*adafruit\_crickit.Crickit attribute*), 15

drive\_stepper\_motor (*adafruit\_crickit.Crickit attribute*), 15

**F**

feather\_drive\_1 (*adafruit\_crickit.Crickit attribute*), 15

feather\_drive\_2 (*adafruit\_crickit.Crickit attribute*), 15

feather\_drive\_3 (*adafruit\_crickit.Crickit attribute*), 15

feather\_drive\_4 (*adafruit\_crickit.Crickit attribute*), 15

feather\_drive\_stepper\_motor  
(*adafruit\_crickit.Crickit attribute*), 15

**I**

init\_neopixel () (*adafruit\_crickit.Crickit method*), 15

**N**

neopixel (*adafruit\_crickit.Crickit attribute*), 15

**O**

onboard\_pixel (*adafruit\_crickit.Crickit attribute*), 15

**R**

raw\_value (*adafruit\_crickit.CrickitTouchIn attribute*), 16

reset () (*adafruit\_crickit.Crickit method*), 15

**S**

seesaw (*adafruit\_crickit.Crickit attribute*), 15

servo\_1 (*adafruit\_crickit.Crickit attribute*), 16

servo\_2 (*adafruit\_crickit.Crickit attribute*), 16

servo\_3 (*adafruit\_crickit.Crickit attribute*), 16

servo\_4 (*adafruit\_crickit.Crickit attribute*), 16

SIGNAL1 (*adafruit\_crickit.Crickit attribute*), 14

SIGNAL2 (*adafruit\_crickit.Crickit attribute*), 14

SIGNAL3 (*adafruit\_crickit.Crickit attribute*), 14

SIGNAL4 (*adafruit\_crickit.Crickit attribute*), 14

SIGNAL5 (*adafruit\_crickit.Crickit attribute*), 14

SIGNAL6 (*adafruit\_crickit.Crickit attribute*), 14

SIGNAL7 (*adafruit\_crickit.Crickit attribute*), 14

SIGNAL8 (*adafruit\_crickit.Crickit attribute*), 14

stepper\_motor (*adafruit\_crickit.Crickit attribute*), 16

**T**

touch\_1 (*adafruit\_crickit.Crickit attribute*), 16

touch\_2 (*adafruit\_crickit.Crickit attribute*), 16

touch\_3 (*adafruit\_crickit.Crickit attribute*), 16

touch\_4 (*adafruit\_crickit.Crickit attribute*), 16

## V

value (*adafruit\_crickit.CrickitTouchIn* attribute), 16