
dclab Documentation

Release 0.3.3

Paul Müller

Apr 17, 2018

Contents:

1 Examples	3
1.1 Plotting isoelastics	3
2 Command line interface	5
2.1 tdms2rtdc	5
2.1.1 Positional Arguments	5
2.1.2 Named Arguments	5
2.2 verify-dataset	5
2.2.1 Positional Arguments	6
3 Code reference	7
3.1 definitions	7
3.2 downsampling	7
3.3 features	8
3.4 isoelastics	8
3.5 kde_methods	10
3.6 polygon_filter	12
3.7 rtdc_dataset	13
3.8 statistics	13
4 Bibliography	15
5 Indices and tables	17
Bibliography	19
Python Module Index	21


Dclab is a Python library for python library for the post-measurement analysis of real-time deformability cytometry (RT-DC) data sets. This is the documentation of dclab version 0.3.3.

CHAPTER 1

Examples

1.1 Plotting isoelastics

This example illustrates how to plot dclab isoelastics by reproducing figure 3 (lower left) of [MMM+17].



isoelastics.py

```
1 import matplotlib.pyplot as plt
2 import matplotlib.lines as mlines
3 from matplotlib import cm
4 import numpy as np
5
```

```
6 import dclab
7
8 # parameters for isoelastics
9 kwargs = {"coll": "area_um", # x-axis
10    "col2": "deform", # y-axis
11    "channel_width": 20, # [um]
12    "flow_rate": 0.04, # [ul/s]
13    "viscosity": 15, # [Pa s]
14    "add_px_err": False # no pixelation error
15    }
16
17 isos = dclab.isoelastics.get_default()
18 analy = isos.get(method="analytical", **kwargs)
19 numer = isos.get(method="numerical", **kwargs)
20
21 plt.figure(figsize=(8, 4))
22 ax = plt.subplot(111, title="elastic sphere isoelasticity lines")
23 colors = cm.get_cmap("jet")(x) for x in np.linspace(0, 1, len(analy)))
24 for aa, nn, cc in zip(analy, numer, colors):
25     ax.plot(aa[:, 0], aa[:, 1], color=cc)
26     ax.plot(nn[:, 0], nn[:, 1], color=cc, ls=":")
27
28 line = mlines.Line2D([], [], color='k', label='analytical')
29 dotted = mlines.Line2D([], [], color='k', ls=":", label='numerical')
30 ax.legend(handles=[line, dotted])
31
32 ax.set_xlim(50, 240)
33 ax.set_ylim(0, 0.02)
34 ax.set_xlabel(dclab.dfn.feature_name2label["area_um"])
35 ax.set_ylabel(dclab.dfn.feature_name2label["deform"])
36
37 plt.tight_layout()
38 plt.show()
```

CHAPTER 2

Command line interface

2.1 tdms2rtdc

Convert RT-DC .tdms files to the hdf5-based .rtdc file format. Note: Do not delete original .tdms files after conversion. The conversion might be incomplete.

```
usage: dclab-tdms2rtdc [-h] [--compute-ancillary-features] tdms-path rtdc-path
```

2.1.1 Positional Arguments

tdms-path	Input path (tdms file or folder containing tdms files)
rtdc-path	Output path (file or folder), existing data will be overridden

2.1.2 Named Arguments

--compute-ancillary-features Compute features, such as volume or emodulus, that are otherwise computed on-the-fly. Use this if you want to minimize analysis time in e.g. ShapeOut. CAUTION: ancillary feature recipes might be subject to change (e.g. if an error is found in the recipe). Disabling this option maximizes compatibility with future versions and allows to isolate the original data.

Default: False

2.2 verify-dataset

Check experimental data sets for completeness. Note that old measurements will most likely fail this verification step. This program is used to enforce data integrity with future implementations of RT-DC recording software (e.g. ShapeIn).

```
usage: dclab-verify-dataset [-h] path
```

2.2.1 Positional Arguments

path	Path to experimental dataset
-------------	------------------------------

CHAPTER 3

Code reference

3.1 definitions

Naming conventions

3.2 downsampling

Content-based downsampling of ndarrays

`dclab.downsampling.downsample_rand(a, samples, remove_invalid=True, retidx=False)`

Downsampling by randomly removing points

Parameters

- `a` (*1d ndarray*) – The input array to downsample
- `samples` (*int*) – The desired number of samples
- `remove_invalid` (*bool*) – Remove nan and inf values before downsampling
- `retidx` (*bool*) – Also return a boolean array that corresponds to the downsampled indices in *a*.

Returns

- `dsa, dsb` (*1d ndarrays of shape (samples,)*) – The pseudo-randomly downsampled arrays *a* and *b*
- `[idx]` (*1d boolean array with same shape as a*) – A boolean array such that *a[idx] == dsa* is all true

3.3 features

Basic methods for event feature computation

3.4 isoelastics

Isoelastics management

```
class dclab.isoelastics.Isoelastics(paths=[])
```

```
add(isoel, col1, col2, channel_width, flow_rate, viscosity, method)
```

Add isoelastics

Parameters

- **isoel** (*list of ndarrays*) – Each list item resembles one isoelastic line stored as an array of shape (N,3). The last column contains the emodulus data.
- **col1** (*str*) – Name of the first feature of all isoelastics (e.g. isoel[0][:,0])
- **col2** (*str*) – Name of the second feature of all isoelastics (e.g. isoel[0][:,1])
- **channel_width** (*float*) – Channel width in μm
- **flow_rate** (*float*) – Flow rate through the channel in $\mu\text{l}/\text{s}$
- **viscosity** (*float*) – Viscosity of the medium in $\text{mPa}\cdot\text{s}$
- **method** (*str*) – The method used to compute the isoelastics (must be one of *VALID_METHODS*).

Notes

The following isoelastics are automatically added for user convenience:

- isoelastics with *col1* and *col2* interchanged
- isoelastics for circularity if deformation was given

```
static add_px_err(isoel, col1, col2, px_um, inplace=False)
```

Undo pixelation correction

Isoelasticity lines are already corrected for pixelation effects as described in

Mapping of Deformation to Apparent Young's Modulus in Real-Time Deformability Cytometry Christoph Herold, arXiv:1704.00572 [cond-mat.soft] (2017) <https://arxiv.org/abs/1704.00572>.

If the isoelasticity lines are displayed with deformation data that are not corrected, then the lines must be “un”-corrected, i.e. the pixelation error must be added to the lines to match the experimental data.

Parameters

- **isoel** (*list of 2d ndarrays of shape (N, 3)*) – Each item in the list corresponds to one isoelasticity line. The first column is defined by *col1*, the second by *col2*, and the third column is the emodulus.
- **col2** (*col1*,) – Define the fist to columns of each isoelasticity line. One of [“area_um”, “circ”, “deform”]
- **px_um** (*float*) – Pixel size [μm]

```
static check_col12(col1, col2)
```

```
static convert(isoel, col1, col2, channel_width_in, channel_width_out, flow_rate_in,
               flow_rate_out, viscosity_in, viscosity_out, inplace=False)
```

Convert isoelastics in area_um-deform space

Parameters

- **isoel** (*list of 2d ndarrays of shape (N, 3)*) – Each item in the list corresponds to one isoelasticity line. The first column is defined by *col1*, the second by *col2*, and the third column is the emodulus.
- **col2** (*col1*,) – Define the fist to columns of each isoelasticity line. One of [“area_um”, “circ”, “deform”]
- **channel_width_in** (*float*) – Original channel width [μm]
- **channel_width_out** (*float*) – Target channel width [μm]
- **flow_rate_in** (*float*) – Original flow rate [$\mu\text{l/s}$]
- **flow_rate_out** – Target flow rate [$\mu\text{l/s}$]
- **viscosity_in** (*float*) – Original viscosity [mPa*s]
- **viscosity_out** (*float*) – Target viscosity [mPa*s]

Notes

If only the positions of the isoelastics are of interest and not the value of the elastic modulus, then it is sufficient to supply values for the channel width and set the values for flow rate and viscosity to a constant (e.g. 1).

See also:

`dclab.features.emodulus.convert()` conversion method used

```
get(col1, col2, method, channel_width, flow_rate=None, viscosity=None, add_px_err=False,
     px_um=None)
```

Get isoelastics

Parameters

- **col1** (*str*) – Name of the first feature of all isoelastics (e.g. `isoel[0][:,0]`)
- **col2** (*str*) – Name of the second feature of all isoelastics (e.g. `isoel[0][:,1]`)
- **method** (*str*) – The method used to compute the isoelastics (must be one of `VALID_METHODS`).
- **channel_width** (*float*) – Channel width in μm
- **flow_rate** (*float or None*) – Flow rate through the channel in $\mu\text{l/s}$. If set to *None*, the flow rate of the imported data will be used (only do this if you do not need the correct values for elastic moduli).
- **viscosity** (*float or None*) – Viscosity of the medium in mPa*s. If set to *None*, the flow rate of the imported data will be used (only do this if you do not need the correct values for elastic moduli).
- **add_px_err** (*bool*) – If True, add pixelation errors according to C. Herold (2017), <https://arxiv.org/abs/1704.00572>
- **px_um** (*float*) – Pixel size [μm], used for pixelation error computation

See also:

`dclab.features.emodulus.convert()` conversion in-between channel sizes and viscosities
`dclab.features.emodulus.corrpix_deform_delta()` pixelation error that is applied to the deformation data

load_data (*path*)
Load isoelastics from a text file

The text file is loaded with `numpy.loadtxt` and must have three columns, representing the two data columns and the elastic modulus with units defined in `definitions.py`. The file header must have a section defining meta data of the content like so:

```
# [...] # # - column 1: area_um # - column 2: deform # - column 3: emodulus # - channel width  
[um]: 20 # - flow rate [ul/s]: 0.04 # - viscosity [mPa*s]: 15 # - method: analytical # # [...]
```

Parameters `path` (*str*) – Path to a isoelastics text file

class `dclab.isoelastics.IsoelasticsDict`

`dclab.isoelastics.get_default()`

Return default isoelasticity lines

3.5 kde_methods

Kernel Density Estimation methods

`dclab.kde_methods.get_bad_vals` (*x, y*)

`dclab.kde_methods.ignore_nan_inf` (*kde_method*)

Ignores nans and infs from the input data

Invalid positions in the resulting density are set to nan.

`dclab.kde_methods.kde_gauss` (*events_x, events_y, xout=None, yout=None, *args, **kwargs*)

Gaussian Kernel Density Estimation

Parameters

- **events_y** (*events_x*,) – The input points for kernel density estimation. Input is flattened automatically.
- **yout** (*xout*,) – The coordinates at which the KDE should be computed. If set to none, input coordinates are used.

Returns `density` – The KDE for the points in (*xout, yout*)

Return type ndarray, same shape as *xout*

See also:

`scipy.stats.gaussian_kde`

Notes

This is a wrapped version that ignores nan and inf values.

dclab.kde_methods.**kde_histogram**(*events_x*, *events_y*, *xout=None*, *yout=None*, *args, **kwargs)
Histogram-based Kernel Density Estimation

Parameters

- **events_y** (*events_x*,) – The input points for kernel density estimation. Input is flattened automatically.
- **yout** (*xout*,) – The coordinates at which the KDE should be computed. If set to none, input coordinates are used.
- **bins** (*tuple (binsx, binsy)*) – The number of bins to use for the histogram.

Returns **density** – The KDE for the points in (xout, yout)

Return type ndarray, same shape as *xout*

See also:

numpy.histogram2d *scipy.interpolate.RectBivariateSpline*

Notes

This is a wrapped version that ignores nan and inf values.

dclab.kde_methods.**kde_none**(*events_x*, *events_y*, *xout=None*, *yout=None*)
No Kernel Density Estimation

Parameters

- **events_y** (*events_x*,) – The input points for kernel density estimation. Input is flattened automatically.
- **yout** (*xout*,) – The coordinates at which the KDE should be computed. If set to none, input coordinates are used.

Returns **density** – The KDE for the points in (xout, yout)

Return type ndarray, same shape as *xout*

Notes

This method is a convenience method that always returns ones in the shape that the other methods in this module produce.

dclab.kde_methods.**kde_multivariate**(*events_x*, *events_y*, *xout=None*, *yout=None*, *args, **kwargs)
Multivariate Kernel Density Estimation

Parameters

- **events_y** (*events_x*,) – The input points for kernel density estimation. Input is flattened automatically.
- **bw** (*tuple (bwx, bwy)* or *None*) – The bandwidth for kernel density estimation.
- **yout** (*xout*,) – The coordinates at which the KDE should be computed. If set to none, input coordinates are used.

Returns **density** – The KDE for the points in (xout, yout)

Return type ndarray, same shape as *xout*

See also:

`statsmodels.nonparametric.kernel_density.KDEMultivariate`

Notes

This is a wrapped version that ignores nan and inf values.

3.6 polygon_filter

PolygonFilter classes and methods

```
class dclab.polygon_filter.PolygonFilter(axes=None, points=None, inverted=False,
                                         name=None, filename=None, fileid=0,
                                         unique_id=None)
```

An object for filtering RTDC data based on a polygonal area

```
instances = []
```

```
static clear_all_filters()
```

Remove all filters and reset instance counter

```
copy(invert=False)
```

Return a copy of the current instance

Parameters `invert` (`bool`) – The copy will be inverted w.r.t. the original

```
filter(datax, datay)
```

Filter a set of datax and datay according to `self.points`

```
static get_instance_from_id(unique_id)
```

Get an instance of the `PolygonFilter` using a unique id

```
static import_all(path)
```

Import all polygons from a .poly file.

Returns a list of the imported polygon filters

```
static instance_exists(unique_id)
```

Determine whether an instance with this unique id exists

```
static point_in_poly(x, y, poly)
```

Determine whether a point is within a polygon area

Parameters

- `y` (`x,`) – The coordinates of the point
- `poly` (`list-like`) – The polygon (`PolygonFilter.points`)

Returns `inside` – `True`, if point is inside.

Return type `bool`

```
static remove(unique_id)
```

Remove a polygon filter from `PolygonFilter.instances`

```
save(polyfile, ret_fobj=False)
```

Save all data to a text file (appends data if file exists).

Polyfile can be either a path to a file or a file object that was opened with the write “w” parameter. By using the file object, multiple instances of this class can write their data.

If `ret_fobj` is `True`, then the file object will not be closed and returned.

```
static save_all (polyfile)
    Save all polygon filters

exception dclab.polygon_filter.PolygonFilterError

dclab.polygon_filter.get_polygon_filter_names()
    Get the names of all polygon filters in the order of creation
```

3.7 rtdc_dataset

3.8 statistics

Statistics computation for RT-DC dataset instances

```
class dclab.statistics.Statistics (name, method, req_feature=False)
    available_methods = {'Flow rate': <dclab.statistics.Statistics object>, 'Median': <...>
    get_feature (rtdc_ds, axis)
    get_data (kwargs)
    dclab.statistics.flow_rate (mm)
    dclab.statistics.get_statistics (rtdc_ds, methods=None, features=None)
```

Parameters

- **rtdc_ds** (instance of `dclab.rtdc_dataset.RTDCBase.`) – The data set for which to compute the statistics.
- **methods** (*list of str or None*) – The methods with which to compute the statistics. The list of available methods is given with `dclab.statistics.Statistics.available_methods.keys()`. If set to `None`, statistics for all methods are computed.
- **features** (*list of str*) – Feature name identifiers are defined in `dclab.definitions.feature_names`. If set to `None`, statistics for all axes are computed.

Returns

- **header** (*list of str*) – The header (feature + method names) of the computed statistics.
- **values** (*list of float*) – The computed statistics.

```
dclab.statistics.mode (data)
```

Compute an intelligent value for the mode

The most common value in experimental is not very useful if there are a lot of digits after the comma. This method approaches this issue by rounding to bin size that is determined by the Freedman–Diaconis rule.

Parameters **data** (*1d ndarray*) – The data for which the mode should be computed.

Returns **mode** – The mode computed with the Freedman-Diaconis rule.

Return type `float`

CHAPTER 4

Bibliography

CHAPTER 5

Indices and tables

- genindex
- modindex
- search

Bibliography

[MMM+17] M. Mokbel, D. Mokbel, A. Mietke, N. Träber, S. Girardo, O. Otto, J. Guck, and S. Aland. Numerical simulation of real-time deformability cytometry to extract cell mechanical properties. *ACS Biomaterials Science & Engineering*, 3(11):2962–2973, jan 2017. doi:10.1021/acsbiomaterials.6b00558.

Python Module Index

d

`dclab.definitions`, 7
`dclab.downsampling`, 7
`dclab.features`, 8
`dclab.isoelastics`, 8
`dclab.kde_methods`, 10
`dclab.polygon_filter`, 12
`dclab.rtdc_dataset`, 13
`dclab.statistics`, 13

Index

A

add() (dclab.isoelastics.Isoelastics method), 8
add_px_err() (dclab.isoelastics.Isoelastics static method), 8
available_methods (dclab.statistics.Statistics attribute), 13

C

check_col12() (dclab.isoelastics.Isoelastics static method), 8
clear_all_filters() (dclab.polygon_filter.PolygonFilter static method), 12
convert() (dclab.isoelastics.Isoelastics static method), 8
copy() (dclab.polygon_filter.PolygonFilter method), 12

D

dclab.definitions (module), 7
dclab.downsampling (module), 7
dclab.features (module), 8
dclab.isoelastics (module), 8
dclab.kde_methods (module), 10
dclab.polygon_filter (module), 12
dclab.rtdc_dataset (module), 13
dclab.statistics (module), 13
downsample_rand() (in module dclab.downsampling), 7

F

filter() (dclab.polygon_filter.PolygonFilter method), 12
flow_rate() (in module dclab.statistics), 13

G

get() (dclab.isoelastics.Isoelastics method), 9
get_bad_vals() (in module dclab.kde_methods), 10
get_data() (dclab.statistics.Statistics method), 13
get_default() (in module dclab.isoelastics), 10
get_feature() (dclab.statistics.Statistics method), 13
get_instance_from_id() (dclab.polygon_filter.PolygonFilter static method), 12
get_polygon_filter_names() (in module dclab.polygon_filter), 13

get_statistics() (in module dclab.statistics), 13

I

ignore_nan_inf() (in module dclab.kde_methods), 10
import_all() (dclab.polygon_filter.PolygonFilter static method), 12
instance_exists() (dclab.polygon_filter.PolygonFilter static method), 12
instances (dclab.polygon_filter.PolygonFilter attribute), 12

Isoelastics (class in dclab.isoelastics), 8

IsoelasticsDict (class in dclab.isoelastics), 10

K

kde_gauss() (in module dclab.kde_methods), 10
kde_histogram() (in module dclab.kde_methods), 10
kde_multivariate() (in module dclab.kde_methods), 11
kde_none() (in module dclab.kde_methods), 11

L

load_data() (dclab.isoelastics.Isoelastics method), 10

M

mode() (in module dclab.statistics), 13

P

point_in_poly() (dclab.polygon_filter.PolygonFilter static method), 12
PolygonFilter (class in dclab.polygon_filter), 12
PolygonFilterError, 13

R

remove() (dclab.polygon_filter.PolygonFilter static method), 12

S

save() (dclab.polygon_filter.PolygonFilter method), 12
save_all() (dclab.polygon_filter.PolygonFilter static method), 13
Statistics (class in dclab.statistics), 13